

You always get more for your money at Kellyco!

Toll FREE 1-888-KELLYCO (1-888-535-5926) www.kellycodetectors.com

Kellyco Metal Detector SuperStore 1085 Belle Ave. Winter Springs, Florida 32708



Field Guide





Power

Turns the detector On/Off.



Mode

Toggles between Coin & Treasure Mode () and Prospecting Mode (). Activates Target ID Stabiliser. Selects the automatic option for Ground Balance and Noise Cancel.



Patterns

Scrolls through the different Discrimination Patterns.



All Metal

Toggles between the selected discrimination pattern and the All Metal pattern.



Minus

Adjusts settings, and scrolls to the left through the discrimination segments.



Menu

Enters the Menu. Accesses and scrolls through the detecting settings.



Pinpoint/Detect

Pinpoint assists in locating the exact position of a target prior to recovery. Detect exits menu settings and returns to detection.



Plus

Adjusts settings, and scrolls to the right through the discrimination segments.



Accept/Reject

Accepts or rejects discrimination segments.



Ground Balance

Accesses the Ground Balance Menu




Track

Toggles between Ground Balance and Tracking Ground Balance.



Backlight

Turns the Backlight On/Off.



■■) Battery

Indicates remaining power.



Indicates headphones are connected.

Backlight

Indicates that the Backlight is on.

Target Stability

Indicates that Target Stability is on.

Reject Identification

Appears when you reject a discrimination segment.

Discrimination Scale •••

(\$) Coin & Treasure

Indicates that you are in the Coin & Treasure Detect Mode.

Prospecting

Indicates that you are in the Prospecting Detect Mode.

₹ Track

Indicates that Tracking Ground Balance is active.

Beach

Indicates that Ground Balance Beach is active.

Sensitivity

Indicates that you are in the Sensitivity menu.

Depth Gauge ·····

Ground Balance

Indicates that you are in the Ground Balance menu.

Noise Cancel

Indicates that you are in the Noise Cancel menu.

▲ Threshold

Indicates that you are in the Threshold menu.

■Volume

Indicates that you are in the Volume menu.

Tones

Indicates that you are in the Tones menu.

QUICK START

1 Turn on (p. 12)

Choose a detecting mode (p. 12)

Coin O Transvira Mada

Coin & Treasure Mode (p. 18)

Prospecting Mode (p. 19)

- 3 Choose a Discrimination Pattern (pp. 22–24) Set the Iron Mask Level (pp. 22–24)
- A Set Noise Cancel (Auto or Manual) (pp. 32–33)
- **5** Set Ground Balance (Auto, Manual or Track) (pp. 40–43)
- 6 Begin detecting!